

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

DBI3 V01 Firmware Updates

Document summarizes DBI3-V01 firmware updates from revision 1.2. Future updates will be added to later revisions of this document.

Firmware revision 1.4 Updates

Display timeouts

For **setup**, **info** and new **windlog** display, there is now a 60 sec timeout then return to **flight** display. Timeout is reset on button action.

Buttons sequence

Buttons sequence for **Fn** button selection e.g. **Info**, **Setup** and **OFF** is changed so that **Fn** button must be pressed prior to **I**, **S** or **OFF** button.

Cryptic "NAN" readout

On a hardware fault a "NAN" display for altitude, rate of climb and temperature has been read out. This is now changed to "Fault".

Log indicator

A log indicator "log.." now appears at top left part of display. Log indicator is shown when log running.

Command Line Interface

Command line interface is extended with commands for all setup items and flight data readout.

Variometer sound indicator

Sound indication for climb and descend is now implemented and can be enabled from setup display. Different sound signature and threshold for climb and descend.

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

GPS altitude and GPS Datum in log file

GPS altitude and GPS set datum is now added to each log record.

Course over ground indicator

For very slow GPS speed over ground conditions, course over ground indicator now show "slow" instead of "---" which was cryptic.

Auto off display

During auto-off sequence and when auto-off is enabled, "OFF" is displayed after an audible sound warning prior to instrument turn off. Button activity will interrupt and reset auto-off timeout.

Wireless ambient temp support

Wireless ambient temp is now supported. When active, ambient temp display is prioritized with 1) wireless sensor, 2) cable sensor and 3) and with lowest priority, enclosure sensor. Ambient temp sensor source is indicated as: **AW** for wireless, **AC** for cable and **A** for enclosure.

Wind history display

Wind history display (windlog) is shown by press and hold **Fn** button for more than 2 secs.

Display shows altitude, speed over ground and course over ground for the latest 36 minutes of flight with 6 minutes intervals. Button action or timeout return to flight display.

Spurious premature stop

Spurious stop for flight timer and log session now cured.

Battery monitor

Battery monitor (battery fuel gage) is now improved to present an equitable readout.

This is most notable at extra low operating temperatures.

Wireless signal strength info page

A new info page is added showing received signal strength. Page shows transmitters code and received signal strength. Signal strength unit is in dBm. Typical receiver sensitivity is -90 dBm.

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

Command Line Interface FW rev 1.4

rst - restart system

? - show help

ri - rtc init

rs yyyy mm dd hh mm ss - rtc set

po - turn hard off

sm on|off - sim data

su alt {feet|meter} | roc {fpm|mps} | bar {ihg|hpa} | temp {fahr|cent} | sog {knot|mps|kmh|mph}
- set units

sa alth {off|value} | altl {off|value} | clmb {off|value} | desc {off|value} | topt {off|value} - set alarm

sf aut {off|static|timeout} | frs {off|pon|toff|toffc|lapc} | aof {off|on} | dat {222-0} - set funcs

sv resp {6.0-1.2} | audio {off|on} | clmbt {value} | desct {value} - set vario

st top {4-1} {off|9999-1} | amb {2-1} {off|9999-1} - set topt

gu alt|roc|bar|temp|sog - get units

ga alth|altl|clmb|desc|topt - get alarm

gf aut|frs|aof|dat - get funcs

gv resp|audio|clmbt|desct - get vario

gt top{4-1}|amb{2-1} - get topt

sd met|imp|urb - set defaults

fs vinit|vdel|start|stop|list|del [filename]|read[filename]|state|clear - file system

si mod|brd|date|loc{adr} str - set info

gi mod|brd|date|loc{adr} - get info

md mach|con - set CLI mode, machine or console

sn - print serialnumber

vr - print firmware version

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

gl {360-1} - get wlog data

rd presm|presb|bar|alt|roc|top|amb|ambc|ambw|lap|long|lat|sog|cog|utc|msl|all - read DBI3 flight data

cc - battery fuel gage

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

Firmware revision 1.6 Updates

DBI3 V01 Firmware version 1.6

Max Values Info Page

A **MAX** value **INFO** page is added. Max values for:

- Altitude
- Baro setting when max altitude was stored, displayed together with stored max altitude
- Climb
- Descend
- Top Temp
- Speed Over Ground

are stored and displayed with **MAX** page selected. Values are reset from instrument power on.

Loss of Top Temp function

A possible loss of top temp function has been corrected. Problem occurred when rate of foreign messages received was high.

Added UTC time Readout on Display

Double pressing **Fn** button replace Elap-time display with UTC-time for a 4 second fixed timeout.

The normal **Fn** button double press Altimeter Unit Toggle (AUT) function is still there.

Faster TOPT Code setup function

While setting TOPT Code, press and hold up/down button will automatically switch over from x1 to x10 to x100 then x1000 increment/decrement. Saves time and lowers Pilots In Command blood-pressure.

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

Command Line Interface FW rev 1.6

Perform warm reboot

rst - restart system

Show help contents

? - show help

Initialize Real Time Clock

ri - rtc init

Set Real Time Clock

rs yyyy mm dd hh mm ss - rtc set

Power off instrument

po - turn hard off

Simulation mode on or off

sm on|off - sim data

Set instruments units

su alt {feet|meter} | roc {fpm|mps} | bar {ihg|hpa} | temp {fahr|cent} | sog {knot|mps|kmh|mph}
- set units

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

Set instrument alarms

sa alth {off|value} | altl {off|value} | clmb {off|value} | desc {off|value} | topt {off|value} - set alarm

Set instrument functions

sf aut {off|static|timeout} | frs {off|pon|toff|toffc|lapc} | aof {off|on} | dat {222-0} - set funcs

Set instrument variometer

sv resp {6.0-1.2} | audio {off|on} | clmbt {value} | desct {value} - set vario

Set instrument top and ambient temp code

st top {4-1} {off|9999-1} | amb {2-1} {off|9999-1} - set topt

Get instrument unit settings

gu alt|roc|bar|temp|sog - get units

Get instrument alarm settings

ga alth|altl|clmb|desc|topt - get alarm

Get instrument function settings

gf aut|frs|aof|dat - get funcs

Get variometer settings

gv resp|audio|clmbt|desct - get vario

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

Get top and ambient temp code settings

gt top{4-1}|amb{2-1} - get topt

Set defaults (settings), metric, imperial or urb

sd met|imp|urb - set defaults

File system commands

fs vinit|vdel|start|stop|list|del [filename]|read[filename]|state|clear - file system

Set nonvolatile info parameters

si mod|brd|date|loc{adr} str - set info

Get nonvolatile info parameters

gi mod|brd|date|loc{adr} - get info

Set console mode

md mach|con - set CLI mode, machine or console

Print instrument serialnumber

sn - print serialnumber

Print firmware version

vr - print firmware version

DBI3-V01	URRA
dbi3_v01_fw_updates_2021_02_01.odt	DBI3 V0.1 Firmware Updates

Get windlog data

gl {360-1} - get wlog data

Read instrument flight data

rd presm|presb|bar|alt|roc|top|amb|ambc|ambw|lap|long|lat|sog|cog|utc|msl|all - read DBI3 flight data

Read instrument battery status

cc - battery fuel gage